



## Fragment Retention Film and Optional Attachment Systems

### Window Film Installation Step by Step:



Spray glass with a soap and water solution. Filtered water with a baby shampoo.

Clean entire glass surface with 6" stainless steel blade.



Cut film with window film slitter to fit each window.

Wipe edges and spray window again with soap and water solution. Using a 12" window cleaning squeegee, squeegee off the soap and water.



617 Keith Lane Owings, MD 20736  
(410) 257-5511 Fax (410) 257-5361  
[www.xlnttint.com](http://www.xlnttint.com)



Remove release liner and spray adhesive with soap and water solution. Place on glass and position into place.



Using our custom designed squeegee, remove all water from under the film. Repeat squeegee process with overlapping passes.

Use a hard card wrapped in a paper towel to remove any excess water from all edges.



Dry all edges and wipe off film of any water marks. Let dry at least 24 hours before any attachment systems are installed.

617 Keith Lane Owings, MD 20736  
(410) 257-5511 Fax (410) 257-5361  
[www.xlnttint.com](http://www.xlnttint.com)